

BA227

Button Battery

Installation Instructions

Battery Tester Model No. BA227 uses a button battery (size 2032) to maintain its settings and retain customer inputs such as details that appear on the printout. The battery comes separate from the tester to support battery longevity. To install the battery, follow the steps below.

1. Remove rubber cover from the BA227 unit.
2. Remove the battery cover on the back of the unit.
3. Install the button battery in the now exposed battery slot, with the “+” facing out.
4. Reattach the battery cover on the back of the BA227 unit.
5. Reinstall the rubber cover over the BA227 unit.
6. Unit is now ready to begin using (you will need to connect to a battery to activate the display).

Step 1: Remove rubber cover



Step 3: Battery installation

